

Bedside Mix – Vabomere Eclipse Ball Pre-Infusion Preparations

https://www.youtube.com/watch?v=rJI8xurPJdl&feature=emb_logo
For additional education please contact your agency for



Use Phone Camera to View Video

Four Steps for Performing Infusions:

Practice good hand-washing

Prepare supplies and mix medication

1

Drawing up medication

3

Injecting the medication into the device

STEP 1: PRACTICE GOOD HAND-WASHING

Always remember to WASH YOUR HANDS for a full 20 seconds when instructed.
STEP 2: PREPARE SUPPLIES
Locate a dry, hard surface and clean the area.
WASH HANDS. Gather the medication vial(s) and diluent vial(s). Gather an eclipse device for use.
Check the medication vials with your orders. Check the medication label with the orders.
WASH HANDS. Gather the following supplies: 6 alcohol wipes; 4 Normal Saline syringes, 2 30ml syringe, 2 mini spike transfers devices, sharps container & trash bag. WASH HANDS.
Remove the mini transfer spikes and saline syringes from packaging and attach to each other.
Disinfect your vial of medication after removing the protective cap And insert transfer device into the vial. Inject saline.
Remove the empty syringe, attach the second syringe and inject into the vial.
STEP 3: DRAWING UP MEDICATION
Attach the 30 ml syringe and gently swirl the vial.
Once fully dissolved, invert the vial and syringe and allow the fluid to fill the syringe pulling back on the plunger as needed.
Remove the filled syringe from the vial by unscrewing it from the transfer device. Remove any air left in the syringe.
STEP 4: INJECTING INTO DEVICE
Remove the white cap on the eclipse device and place on an alcohol pad.
Attach the syringe to the eclipse ball and inject the medication.
Remove the syringe from the eclipse and discard.
Reattach the white cap to the eclipse ball.
Repeat by adding one more medication syringe to the eclipse device.
Discard of all trash in the regular trash.
WASH HANDS.

