

EMERGENCY EQUIPMENT MAINTENANCE LOG

Axion Eyepod Faucet Mounted Eyewash

- Eyewash must be run WEEKLY for at least 3 minutes or until the water is sediment-free.
- Eyewash must be unobstructed
- Water must be tepid (60F – 100F: cool - warm to touch).
- Water must have adequate pressure (flow should be at least 2” and must be less than 8” above the eyewash).
- Clean as needed to keep the eyewash holes free of mineral deposits.

Date Inspected (mm/dd/yyyy)	Location	Inspected By	Equipment In Good Working Condition? CIRCLE YES or NO*	Corrective Actions Taken (if needed)
			YES NO	
			YES NO	
			YES NO	
			YES NO	
			YES NO	

* IF EQUIPMENT IS NOT OPERATING PROPERLY, PROBLEM MUST BE REPORTED TO FACILITIES.
 MAINTAIN COMPLETED EMERGENCY EQUIPMENT MAINTENANCE LOG FOR TWO YEARS