

## WEEKLY EMERGENCY EQUIPMENT MAINTENANCE LOG

### Standard Eyewashes, Drench Hoses, and Combination Units

- Equipment must be run WEEKLY for at least 3 minutes or until the water is sediment-free.
- The equipment must be unobstructed
- Water must come on within one second of activation.
- Water must be tepid (60F – 100F: cool - warm to touch).
- Water must have adequate pressure (for eyewashes, flow should be at least 2” and must be less than 8”above the eyewash ).
- Eyewash caps must be clean and not require a separate motion to remove (they must fall off when the eyewash is activated)
- Clean nozzles as needed to keep them free of mineral deposits.

Date Inspected (mm/dd/yyyy)	Location	Inspected By	Equipment In Good Working Condition? CIRCLE YES or NO*	Corrective Actions Taken (if needed)
			YES      NO	
			YES      NO	
			YES      NO	
			YES      NO	
			YES      NO	

\* IF EQUIPMENT IS NOT OPERATING PROPERLY, PROBLEM MUST BE REPORTED TO FACILITIES.  
 MAINTAIN COMPLETED EMERGENCY EQUIPMENT MAINTENANCE LOG FOR TWO YEARS